How to increase Belt Life

Keep sheaves and belts clean.

Abrasive dust, rust, oil and acids reduce service life.

Give drives elbow room. Never let belts run against belt guards or other obstructions.

Use large diameter sheaves and fewer belts.

You save money and increase drive life.



Never force belts.

Move motor on adjustable base so belts can go on easily.

Eliminate slack.

Adjust motor and tighten belts in position. Slack belts wear excessively, cause slippage and deliver less power.

Use matched belts.

Matched belts run smoother and last longer because the load is evenly distributed. Never replace just part of a set of belts.

Avoid belt idlers.

Belt idlers decrease belt life! Always maintain proper tension through motor adjustment.

Mount belts straight.

Shafts must be parallel and sheave grooves in alignment to prevent unnecessary belt wear.

Don't overload.

An overloaded belt drive is like a one-ton truck with a two-ton load — both are sure to break down. Always use ample capacity.









SHEAVE DIAM - INCHES DEFLECTION FORCE - LBS

	Smallest Sheave Diameter Range	RPM Range	Belt Deflection Force			
Belt Cross Section			Super Gripbelts and Unnotched Gripbands		Gripnotch Belts and Notched Gripbands	
			Used Belt	New Belt	Used Belt	New Belt
A,AX	3.0 - 3.6	1000-2500 2501-4000	3.7 2.8	5.5 4.2	4.1 3.4	6.1 5.0
	3.8 - 4.8	1000-2500 2501-4000	4.5 3.8	6.8 5.7	5.0 4.3	7.4 6.4
	5.0 - 7.0	1000-2500 2501-4000	5.4 4.7	8.0 7.0	5.7 5.1	8.4 7.6
B,BX	3.4 - 4.2	860-2500 2501-4000	-	-	4.9 4.2	7.2 6.2
	4.4 - 5.6	860-2500 2501-4000	5.3 4.5	7.9 6.7	7.1 6.1	10.5 9.1
	5.8 - 8.6	860-2500 2501-4000	6.3 6.0	9.4 8.9	8.5 7.3	12.6 10.9
C,CX	7.0 - 9.0	500-1740 1741-3000	11.5 9.4	17.0 13.8	14.7 11.9	21.8 17.5
	9.5 - 16.0	500-1740 1741-3000	14.1 12.5	21.0 18.5	15.9 14.6	23.5 21.6
D	12.0 - 16.0	200-850 851-1500	24.9 21.2	37.0 31.3	-	-
	18.0 - 20.0	200-850 851-1500	30.4 25.6	45.2 38.0	-	-
3V,3VX	2.2 - 2.4	1000-2500 2501-4000	-	-	3.3 2.9	4.9 4.3
	2.65 - 3.65	1000-2500 2501-4000	3.6 3.0	5.1 4.4	4.2 3.8	6.2 5.6
	4.12 - 6.90	1000-2500 2501-4000	4.9 4.4	7.3 6.6	5.3 4.9	7.9 7.3
5V,5VX	4.4 - 6.7	500-1749 1750-3000 3001-4000	-		10.2 8.8 5.6	15.2 13.2 8.5
	7.1 - 10.9	500-1740 1741-3000	12.7 11.2	18.9 16.7	14.8 13.7	22.1 20.1
	11.8 - 16.0	500-1740 1741-3000	15.5 14.6	23.4 21.8	17.1 16.8	25.5 25.0
8V	12.5 - 17.0	200-850 851-1500	33.0 26.8	49.3 39.9	-	-
	18.0 - 22.4	200-850 851-1500	39.6 35.3	59.2 52.7	-	-

© Emerson Power Transmission Manufacturing, L.P. 1998, 1999. All Rights Reserved.

These BROWNING Gripbelts are accurately machine matched

BROWNING Matched Belts provide a true running drive and longer service life. You can depend on them because they are matched *under tension* — that is, while in the sheave grooves, in motion, under the same conditions encountered during operation.

Fill in the information below detach and tie to machine or file for handy reference when belts need to be replaced.

These BROWNING BELTS were installed:

Machine Description	Date
Factory Location	
Gripbelt Size	
Number of Belts	
Reorder Fro	om:

Do Not Install These Matched **Belts** Until You Read This

Form 8082-C 7/30/99 Printed in U.S.A. © Emerson Power Transmission Manufacturing, L.P. 1998, 1999. All Rights Reserved.



Browning Emerson Power Transmission MAYSVILLE, KY 41056